



**SI-6-18-6-A**  
Replaces SI-6-18-6  
**Installation Instructions**  
RHI-01 Relative Humidity  
Indicator Order No. 130503



1.) Remove end plugs



2.) Attach to tool or Desiccant Snake. Use TWO wrenches to tighten indicator. DO NOT over tighten. When using with Desiccant Snake the Indicator should be placed between the Snake and the spray gun.

3.) Protect the indicator's window from paint overspray. Apply a thin film of DeVilbiss SSL-10 Gun Lube on the window to simplify cleaning.

4.) The indicating beads will change back to blue with contact from dry air.



Blue = Dry Air

Pink/Clear = Humid Air

The Material Safety Data Sheet MSDS-54 is available on request at [www.autorefinishdevilbiss.com](http://www.autorefinishdevilbiss.com)

**WARNING: Risk of injury.**  
Under Pressure. Shut off air supply and release pressure before servicing.

CAUTION: SILICA GEL MAY CAUSE IRRITATION TO SKIN, EYES AND RESPIRATORY TRACT.  
DISCARD IMMEDIATELY IF DAMAGED. FOR COMPRESSED AIR ONLY.  
DO NOT USE FOR BREATHABLE AIR OR OTHER APPLICATIONS.  
NOTE: RISK OF INDICATOR DAMAGE.  
SOME PAINT SOLVENTS MAY DAMAGE THE CLEAR LEXAN WINDOW.



DeVilbiss  
email: [askus@devilbissar.com](mailto:askus@devilbissar.com)  
Customer Service: 800.445.3988  
[www.autorefinishdevilbiss.com](http://www.autorefinishdevilbiss.com)